

## Using Garmin Multisport Watches

To mount a Garmin Multisport watch on the Torpedo Kompact, the quarter turn insert on the Torpedo Kompact will need to be rotated and two additional spacers and two longer screws need to be installed to allow the watch to be mounted. To make these changes, use the following steps:

1. **Remove the retainer** from the rest of the computer mount by undoing the retainer screw (B) with a 2.5mm Hex Wrench. Place down on the table.
2. **Remove the two mounting screws (A)** holding in the insert and remove the insert from the retainer by using a 2mm Hex Wrench.
3. **Insert the new hardware.** Turn the insert upside down and place one of the longer mounting screws upwards through one of the mounting holes and place one of the included spacers over the end of the screw. Repeat for the other screw.
4. **Place the computer mount retainer back** onto the insert while it is still upside down so the screws are lined up with the appropriate threaded holes and turn the assembly back over.
5. **Tighten the two new mounting screws (A)** and torque to 10 in lbs (1.1 Nm).
6. **Reattach the retainer to the computer mount** by inserting the retainer screw (B) and tightening. Torque the screw to 20 in lbs (2.3 Nm).

